

mistley

BATHROOM GLASS

Stand Alone Panel Installation Instructions

Supplied Parts

Channel + rubber cushion strip
Glass Panel
Support arm x 2 with screws, Rawl plugs, grub screws and Allen key

Required Tools

Spirit Level
Pencil
Drill (with bit and screw-driver fitting to match supplied screws)
Sealant gun
High-quality silicone
Measuring Tape
Glass lifters
Setsquare
Junior hacksaw
Masking Tape

Installing this shower screen is a two-person job.

The channel may extend beyond the panel; mark it to the width of the glass.

Using a hacksaw, cut away the spare end of the channel and file smooth.





Determine how far from the wall the glass panel is to be fitted – up to a maximum of 1500mm.

Place the channel onto the floor and mark its position. Insert the rubber cushion strip into the channel.

Lift the channel and apply a bead of silicone to the underside of the channel and reposition it on the floor. Hold the channel in position with masking tape.

Apply continuous beads of silicone along the inside of the floor channel where the glass panel will sit, as shown.

Lift the glass panel into place in the floor channel. One person will need to hold the glass panel upright for steps 5-8, ensuring it is vertical using a spirit level.



The support arms must be cut down to the correct length:

Measure the distance between the inside edge of the glass and the wall in millimetres and subtract 35; the result is the required length of the support arms pole.

Repeat this for the second support arm.

Using a hacksaw cut away the spare end of the pole and file smooth.

Assemble one of the support arms and slide it onto the top edge of the glass panel, about 100mm in from one corner.

Using a spirit level to ensure the arm is horizontal, mark the position of the fluted bracket on the wall using a pencil.

Repeat this for the position of the second support arm.

Drill the wall for the support arm wall screw and insert the Rawl plug. Screw the fluted bracket to the wall.

The grub screw hole should be positioned towards the top of the bracket.

Repeat this for the second support arm.

Re-assemble both support arms and place into position. Tighten the grub screws on both ends. Using the Allen key tighten the glass bracket.

